




VA Series

Vapor Actuated Dial Thermometer




M1982/0902




General Description

The OMEGA® VA Series Vapor Actuated Thermometer is ideal for remote readings, such as panel installations, with capillary lengths from 5 to 100 feet. This thermometer gives excellent readings above and below ambient temperature and, being vapor actuated, is not subject to reading errors due to either RFI/EMI interference or ambient temperature variations along the capillary tube length.


Available Models



Front Flange (Panel Mount)



U-Clamp (Panel Mount)



Rear Flange (Surface Mounted)

Figure 1. Case Style

Model VA Vapor Actuated	Table 1 Case Style & Size	Table 2 Temperature Range	Table 3 Capillary & Bulb	Table 4 Capillary Length (in feet)	Table 5 Process Connection
VA	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
Example:	VA - 20FR	- 21	- D	- 05	- L2

Installing the Vapor Actuated Thermometer

Unpacking Instructions

Remove the Packing List and verify that you have received all equipment, including the following (quantities in parentheses):

- Vapor Actuated Dial Thermometer (1)
- Operator's Manual (1)


If you have any questions about the shipment, please call the OMEGA Customer Service Department.

When you receive the shipment, inspect the container and equipment for signs of damage. Note any evidence of rough handling in transit. Immediately report any damage to the shipping agent.

NOTE

The carrier will not honor damage claims unless all shipping material is saved for inspection. After examining and removing contents, save packing material and carton in the event reshipment is necessary.

Case and Mounting Dimensions



Front Flange
(Panel Mount)

U-Clamp
(Panel Mount)

Rear Flange
(Surface Mount)

Dial Size	A	B	C	D	E	F	G	H	J
1½"	-	1.82	-	-	1.60	.70	-	-	-
2"	2.94	2.24	3.50	1.28R	2.05	1.09	1.59R	2.13	.156
2½"	3.35	2.81	-	1.52R	2.53	.94	-	-	.175
3½"	4.30	3.94	4.67	2.00R	3.69	1.09	2.125R	2.75	.180
4½"	6.25	-	5.83	2.69R	4.87	1.30RF/1.81FF/2.30TB	2.68R	5.00	.230

Figure 2. Case and Mounting Dimensions

Installing the Indicating Head

Surface Mount (Rear Flange)

CODE	DIAL	CASE	LENS	CONNECTION LOCATION
20RR	2"	S.S.	Polycarbonate	Rear
35RR	3 ½"	S.S.	Polycarbonate	Rear
35RA	3 ½"	Black Steel	Glass	Adjustable, Rear or Bottom
45RA	4 ½"	Valox	Glass	Adjustable, Rear or Bottom
45RR	4 ½"	Valox	Glass	Rear
45TB	4 ½"	Phenolic	Glass	Bottom (Turret Mount)

1. Make a circular cutout in the center of the hole mounting pattern for the capillary tube to fit through.
2. Drill the three (3) mounting holes.
3. Using the screw holes that you drilled, screw the back of the head to your wall or panel.



Flush Mount (Front Flange and U-Clamp)

CODE	DIAL	CASE	LENS	CONNECTION LOCATION
20FR	2"	S.S.	Polycarbonate	Rear
20FB	2"	S.S.	Polycarbonate	Bottom
25FR	2½"	S.S.	Polycarbonate	Rear
35FR	3½"	S.S.	Polycarbonate	Rear
45FR	4½"	Black Aluminum	Glass	Lower Rear

CODE	DIAL	CASE	LENS	CONNECTION LOCATION
20UR	2"	S.S.	Polycarbonate	Rear
25UR	2 ½"	S.S.	Polycarbonate	Rear
35UR	3 ½"	S.S.	Polycarbonate	Rear


1. Make a circular cutout in the panel slightly larger than the case.
2. Drill three (3) mounting holes for the Front Flange Model.
3. From the front of the panel, pass the bulb and capillary through the cutout.
4. Affix the head to the panel:
 - 4a. U-clamp Model: Tighten U-clamp(s) against the back of your panel.
 - 4b. Front Flange Model: Screw the flange to the front of your panel, using the screw holes that you drilled.

Installing the Bulb

NOTE

If the bulb is installed more than 10 feet above or below the dial, it may be necessary to recalibrate the instrument.

BULB CONFIGURATIONS



VA Series Vapor Actuated Dial Thermometer

Standard Bulb Dimensions (inches)

CAPILLARY LENGTH	PLAIN BULB		UNION CONNECTION			THERMOWELL			BENDABLE EXT.		
	L	D	U	S	D	U	S	D	L	S	D
1-10 feet	2.62	7/16	2.00	2.68	7/16	2.25	2.93	7/16	2.25	3"-13 1/4"	7/16
11-50 feet	4.62	7/16	4.00	4.68	7/16	4.25	4.93	7/16	4.25	5"-15 1/4"	7/16
51-100 feet	6.62	7/16	6.00	6.68	7/16	6.25	6.93	7/16	6.25	6 1/2"-17 1/4"	7/16

Immerse the thermometer stem at least A inches (or entire stem, whichever is less) in the medium being measured, for best reading.

Union Connections

CODE	CONNECTION TYPE	MATERIAL
J1	None (Plain bulb)	--
J2	Jam Nut Only	Brass (For Existing Brass Well)
J3	Jam Nut Only	316 S.S. (For Existing Stainless Well)
K2	1/2" NPT Union	Brass
L2	1/2" NPT Union	316 S.S.
M2	1/2" NPT Sliding Union on bendable extension	316 S.S.
N2	Thermowell, 1/2" NPT	Brass
N3	Thermowell, 3/4" NPT	Brass
P2	Thermowell, 1/2" NPT	316 S.S.
P3	Thermowell, 3/4" NPT	316 S.S.
Q2	Thermowell, 1/2" NPT	Brass
Q3	Thermowell, 3/4" NPT	Brass
R2	Thermowell, 1/2" NPT	316 S.S.
R3	Thermowell, 3/4" NPT	316 S.S.
S2	Thermowell, 1/2" NPT	Brass
S3	Thermowell, 3/4" NPT	Brass
T2	Thermowell, 1/2" NPT	316 S.S.
T3	Thermowell, 3/4" NPT	316 S.S.

CAUTION



Tighten the thermometer to its fitting using a wrench applied to the hex or flats above the threads. Never tighten by hand.

1. Unscrew and remove the 1/2" NPT fitting, using a 7/8" wrench.
2. Screw the 1/2" NPT fitting into the threaded process opening.
3. Insert the bulb through the 1/2" NPT fitting. Tighten it in place by screwing the jam nut into the top of the 1/2" NPT fitting with an 11/16" wrench.

NOTE

Use a thermowell in all pressurized applications. Be sure case temperature does not exceed 200°F (93°C).

Thermowells

1. Remove the thermowell and screw it into the process so that no leaking occurs. Use thread sealant as required.
2. Place the bulb in the thermowell. Tighten the bulb in place by screwing the jam nut into the top of the ½" fitting with an ⅛" wrench.

Bendable Extensions

- I. Place the bulb in the thermowell, or directly in the process.

NOTE

Use a thermowell whenever the bulb would be exposed to pressure, fluid velocity, or corrosive media.

2. Slide the compression fitting down and screw the ½" NPT fitting into the process (or thermowell) threads.
3. Tighten the top hex of the sliding union until the bendable extension does not slide in or out.
4. Gently bend the remaining portion of the extension out of the way.

Operation

Recommended operating temperature is in the upper ⅓ of the dial scale.

CODE	°F RANGES
20	-40 TO 65°F
30	-40 TO 110°F
32	-20 TO 120°F
72	0 TO 180°F
49	0 TO 150°F
80	20 TO 220°F
50	30 TO 240°F
56	50 TO 250°F
60	30 TO 300°F
68	100 TO 350°F
70	200 TO 450°F

CODE	°F AND °C RANGES
21	-40 TO 65°F / -40 TO 20°C
31	-40 TO 110°F / -40 TO 40°C
33	-20 TO 120°F / -30 TO 50°C
73	0 TO 180°F / -20 TO 80°C
79	0 TO 150°F/-15 TO 65°C
81	20 TO 220°F / 0 TO 105°C
51	30 TO 240°F / 0 TO 115°C
57	50 TO 250°F / 10 TO 120°C
61	30 TO 300°F / 0 TO 150°C
66	100 TO 350°F / 40 TO 180°C
71	200 TO 450°F / 100 TO 230°C



VA Series Vapor Actuated Dial Thermometer

Vapor actuated thermometers give excellent readings when the bulb temperature is either above or below the temperature of the indicating head. Avoid applications in which the bulb and head are the same temperature (ambient applications). If the bulb “crosses ambient” (i.e., goes from hotter than the indicating head to cooler or vice versa), some pointer fluctuations will occur for up to two minutes during this transition.

Recalibration

The VA Series vapor actuated thermometers are manufactured with threaded, press fit and snap-ring lenses which can be easily removed for field calibration.

To recalibrate your vapor actuated thermometer:

1. Remove the thermometer from its fitting.
2. Remove the lens.
4. Immerse the bulb totally in an agitated liquid for at least 3 minutes with a master reference thermometer, until they reach equilibrium.
5. Use a wrench, coin or screwdriver to turn the slotted hex nut on the back of the thermometer case until the pointer is at the proper reading on the scale.
6. Replace the lens and reinstall the thermometer in its fitting.

Care of the Vapor Actuated Thermometer

CODE	CAPILLARY & BULB MATERIAL	CAPILLARY PROTECTION
A	Nickel Plated Copper	-
C	Copper	Bronze Braid
D	316 S.S.	-
E	316 S.S.	S.S. Armor

- Avoid bending the stem, as this will result in frictional errors in indication.
- Do not kink or flatten the capillary tube.
- Dampen any capillary vibration, as this may cause capillary breakage over time.



Specifications

Dial Sizes:	2", 2 ½", 3 ½", 4 ½"
Dial:	Aluminum with white finish and black markings
Pointer:	Furnished standard adjustable
Movement:	Brass with precision gearing
Bourdon Tube:	Phosphor bronze
Accuracy:	Plus or minus one scale division
Case:	Stainless steel on all front flange and U-clamp models. Back flange models in stainless (2"), black steel (3 ½") or Valox (4 ½")
Process Connection:	Plain bulb, ½" NPT Union, ½" NPT sliding union on 12 Connection: bendable extension, or thermowell.
Window:	Polycarbonate. Glass in 3 ½" and 4 ½" back flange models
Bulb:	Stainless steel or nickel plated copper. Bulb O.D. ¾" (optional ¼" O.D. x 2" length on -40 to 65°F range only). Bulb lengths vary from 2" to 6" depending on capillary length
Capillary:	Nickel plated copper, copper with bronze braid armor, stainless steel, stainless steel with stainless steel armor. Capillary lengths 1 to 100 feet (standard length 5 feet)
Ranges:	Over twenty °F and °F/°C ranges available, from -40° to +450°F
Applications:	Control panels, chemical processing, pipelines, food processing, OEM applications, ovens, solar heating,

Vapor actuated thermometers give excellent readings when the bulb temperature is either above or below the temperature of the indicating head. Avoid applications in which the bulb and head are the same temperature (ambient applications). If the bulb "crosses ambient" (i.e., goes from hotter than the indicating



OMEGAnet® Online Service www.omega.com	Internet e-mail info@omega.com
--	--

Servicing North America:

USA: One Omega Drive, Box 407
ISO 9001 Certified Stamford CT 06907-0047
 Tel: (203) 359-1660 FAX: (203) 359-7700
 e-mail: info@omega.com

Canada: 976 Bergar
 Laval (Quebec) H7L 5A1
 Tel: (514) 856-6928 FAX: (514) 856-6886
 e-mail: info@omega.ca

For immediate technical or application assistance:

USA and Canada: Sales Service: 1-800-826-6342 / 1-800-TC-OMEGA®
 Customer Service: 1-800-622-2378 / 1-800-622-BEST®
 Engineering Service: 1-800-872-9436 / 1-800-USA-WHEN®
 TELEX: 996404 EASYLINK: 62968934 CABLE: OMEGA®

Mexico: En Español: (001) 203-359-7803 e-mail: espanol@omega.com
 FAX: (001) 203-359-7807 info@omega.com.mx

Servicing Europe:

Benelux: Postbus 8034, 1180 LA Amstelveen, The Netherlands
 Tel: +31 (0)20 3472121 FAX: +31 (0)20 6434643
 Toll Free in Benelux: 0800 0993344
 e-mail: sales@omegaeang.nl

Czech Republic: Rudé armády 1868, 733 01 Karviná 8
 Tel: +420 (0)69 6311899 FAX: +420 (0)69 6311114
 Toll Free: 0800-1-66342 e-mail: info@omegasph.cz

France: 11, rue Jacques Cartier, 78280 Guyancourt, France
 Tel: +33 (0)1 61 37 29 00 FAX: +33 (0)1 30 57 54 27
 Toll Free in France: 0800 466 342
 e-mail: sales@omega.fr

Germany/Austria: Daimlerstrasse 26, D-75392 Deckenpfronn, Germany
 Tel: +49 (0)7056 9398-0 FAX: +49 (0)7056 9398-29
 Toll Free in Germany: 0800 639 7678
 e-mail: info@omega.de

United Kingdom: One Omega Drive, River Bend Technology Centre
ISO 9002 Certified Northbank, Irlam, Manchester
 M44 5BD United Kingdom
 Tel: +44 (0)161 777 6611 FAX: +44 (0)161 777 6622
 Toll Free in United Kingdom: 0800-488-488
 e-mail: sales@omega.co.uk

It is the policy of OMEGA to comply with all worldwide safety and EMC/EMI regulations that apply. OMEGA is constantly pursuing certification of its products to the European New Approach Directives. OMEGA will add the CE mark to every appropriate device upon certification.

The information contained in this document is believed to be correct, but OMEGA Engineering, Inc. accepts no liability for any errors it contains, and reserves the right to alter specifications without notice.

WARNING: These products are not designed for use in, and should not be used for, patient-connected applications.

**WARRANTY/DISCLAIMER**

OMEGA ENGINEERING, INC. warrants this unit to be free of defects in materials and workmanship for a period of **13 months** from date of purchase. OMEGA's WARRANTY adds an additional one (1) month grace period to the normal **one (1) year product warranty** to cover handling and shipping time. This ensures that OMEGA's customers receive maximum coverage on each product.

If the unit malfunctions, it must be returned to the factory for evaluation. OMEGA's Customer Service Department will issue an Authorized Return (AR) number immediately upon phone or written request. Upon examination by OMEGA, if the unit is found to be defective, it will be repaired or replaced at no charge. OMEGA's WARRANTY does not apply to defects resulting from any action of the purchaser, including but not limited to mishandling, improper interfacing, operation outside of design limits, improper repair, or unauthorized modification. This WARRANTY is VOID if the unit shows evidence of having been tampered with or shows evidence of having been damaged as a result of excessive corrosion; or current, heat, moisture or vibration; improper specification; misapplication; misuse or other operating conditions outside of OMEGA's control. Components which wear are not warranted, including but not limited to contact points, fuses, and triacs.

OMEGA is pleased to offer suggestions on the use of its various products. However, OMEGA neither assumes responsibility for any omissions or errors nor assumes liability for any damages that result from the use of its products in accordance with information provided by OMEGA, either verbal or written. OMEGA warrants only that the parts manufactured by it will be as specified and free of defects. OMEGA MAKES NO OTHER WARRANTIES OR REPRESENTATIONS OF ANY KIND WHATSOEVER, EXPRESS OR IMPLIED, EXCEPT THAT OF TITLE, AND ALL IMPLIED WARRANTIES INCLUDING ANY WARRANTY OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE HEREBY DISCLAIMED. LIMITATION OF LIABILITY: The remedies of purchaser set forth herein are exclusive, and the total liability of OMEGA with respect to this order, whether based on contract, warranty, negligence, indemnification, strict liability or otherwise, shall not exceed the purchase price of the component upon which liability is based. In no event shall OMEGA be liable for consequential, incidental or special damages.

CONDITIONS: Equipment sold by OMEGA is not intended to be used, nor shall it be used: (1) as a "Basic Component" under 10 CFR 21 (NRC), used in or with any nuclear installation or activity; or (2) in medical applications or used on humans. Should any Product(s) be used in or with any nuclear installation or activity, medical application, used on humans, or misused in any way, OMEGA assumes no responsibility as set forth in our basic WARRANTY/DISCLAIMER language, and, additionally, purchaser will indemnify OMEGA and hold OMEGA harmless from any liability or damage whatsoever arising out of the use of the Product(s) in such a manner.

RETURN REQUESTS / INQUIRIES

Direct all warranty and repair requests/inquiries to the OMEGA Customer Service Department. BEFORE RETURNING ANY PRODUCT(S) TO OMEGA, PURCHASER MUST OBTAIN AN AUTHORIZED RETURN (AR) NUMBER FROM OMEGA'S CUSTOMER SERVICE DEPARTMENT (IN ORDER TO AVOID PROCESSING DELAYS). The assigned AR number should then be marked on the outside of the return package and on any correspondence.

The purchaser is responsible for shipping charges, freight, insurance and proper packaging to prevent breakage in transit.

FOR **WARRANTY RETURNS**, please have the following information available BEFORE contacting OMEGA:

1. Purchase Order number under which the product was PURCHASED,
2. Model and serial number of the product under warranty, and
3. Repair instructions and/or specific problems relative to the product.

FOR **NON-WARRANTY REPAIRS**, consult OMEGA for current repair charges. Have the following information available BEFORE contacting OMEGA:

1. Purchase Order number to cover the COST of the repair,
2. Model and serial number of the product, and
3. Repair instructions and/or specific problems relative to the product.

OMEGA's policy is to make running changes, not model changes, whenever an improvement is possible. This affords our customers the latest in technology and engineering.

OMEGA is a registered trademark of OMEGA ENGINEERING, INC.

© Copyright 2002 OMEGA ENGINEERING, INC. All rights reserved. This document may not be copied, photocopied, reproduced, translated, or reduced to any electronic medium or machine-readable form, in whole or in part, without the prior written consent of OMEGA ENGINEERING, INC.